

# OptiJet

inkjet cartridge

CONVENIENT QUALITY!

EPSON  
Printers



OPTIJET CODE	EPSON CODE
E11	T053
E19	T017
E20	T018
E21	T007
E22	T008
E23	T009
E24	T026
E25	T027
E26	T028
E27	T029
E28	T013 - T050
E29	T014 - T052
E30	T051
E31	T036
E32	T037
E33	T040
E34	T041
E35	T0321
E39	T0422
E40	T0423
E41	T0424
E42	T0441
E43	T0452
E44	T0453
E45	T0454
E46	T55704
E47	T0481

E48	T0482
E49	T0483
E50	T0484
E51	T0485
E52	T0486
E53	T0551
E54	T0552
E55	T0553
E56	T0554
E57	T066
E58	T067
E59	T0611
E60	T0612
E61	T0613
E62	T0614
RE1	CHIP RESETER
RE2	CHIP RESETER
RECR	CHIP RESETER

100% compatible  
Accurate colour reproduction is  
guaranteed by OptiJet™ brand.



EPSON MODEL	OPTIJET CODE	EPSON CODE	RESETER
STYLUS COLOR 400-440-460-480-480SXU-580-600-640-660-670	E28 E29		RE1 RE2
STYLUS COLOR 680-685	E19 E20		RE1 RE2 RECR
STYLUS COLOR 740-760-800-850-860-1160-1520	E30 E29		RE1 RE2
STYLUS C20UX-C40UX	E28 E29		RE1 RE2
STYLUS C42UX-C42+-C44+-C44UX-C46	E31 E32		RE1 RE2 RECR
STYLUS C48	E57 E58		RECR
STYLUS C60	E26 E27		RE1 RE2 RECR
STYLUS C62	E33 E34		RE2 RECR
STYLUS C64-C66	E42 E43 E44 E45		RECR
STYLUS C70-C80	E35		RECR
STYLUS C82	E35 E39 E40 E41		RECR
STYLUS C84-C86	E42 E43 E44 E45		RECR
STYLUS CX 3200	E33 E34		RECR
STYLUS CX 5200-CX 5400	E35 E39 E40 E41		RECR
STYLUS CX3600-CX3650-CX6400-CX6600	E42 E43 E44 E45		RECR
STYLUS D68-D88-DX3800-DX3850-DX4200-DX4250-DX4800-DX4850	E59 E60 E61 E62		RECR
STYLUS PHOTO 750	E28 E11		RE1
STYLUS PHOTO 810-820-830	E24 E25		RE1 RECR
STYLUS PHOTO 790-870-875-890-895	E21 E22		RE1 RECR
STYLUS PHOTO 900	E21 E23		RE1 RECR
STYLUS PHOTO 915	E21 E22		RE1 RECR
STYLUS PHOTO 925-935	E24 E25		RE1 RECR
STYLUS PHOTO 1270-1280-1290	E21 E23		RE1 RECR
STYLUS PHOTO R200-R220	E47 E48 E49 E50 E51 E52		RECR
STYLUS PHOTO R240-R245	E53 E54 E55 E56		RECR
STYLUS PHOTO R300-R320-R340	E47 E48 E49 E50 E51 E52		RECR
STYLUS PHOTO RX420-RX425	E53 E54 E55 E56		RECR
STYLUS PHOTO RX500	E47 E48 E49 E50 E51 E52		RECR
STYLUS PHOTO RX520	E53 E54 E55 E56		RECR
STYLUS PHOTO RX600-RX620	E47 E48 E49 E50 E51 E52		RECR
PICTUREMATE-PICTUREMATE 500	E46 E46		
STYLUS SCAN 2000-2500	E30 E29		RE1 RE2

EPSON MODEL	OPTIJET CODE	EPSON CODE
BJC 2000-2100-4000-4100-4200-4300-4400-4550-4650-5000-5100-5500	C1 C2 C3 C4	
BJC 3000-6000-6100-6200-6500	C3	C4 C5 C6 C7 C8 C9
BJC 8200	C12	C13 C14 C15 C16 C17
S100	C1 C2 C3 C4	
S200-i250-S300-i320-S330-i350	C10 C20 C11 C21	
S400-S450-S4500	C3	C4 C5 C6 C7 C8 C9
i450-i455-i470D-i475D	C10 C20 C11 C21	
S500-S520-S530D-i550	C3	C4 C5 C6
i560	C3	C13 C14 C15
S600-S630-S6300-i6500-S750	C3	C4 C5 C6
S800-S820-S830D	C12	C13 C14 C15 C16 C17
i850	C3	C4 C5 C6
i865	C3	C13 C14 C15 C12
S900-S9000-i905D-i9100-i950-i965-i990-i9950	C12	C13 C14 C15 C16 C17
PIXMA iP1500-iP2000	C10 C20 C11 C21	
PIXMA iP3000	C3	C13 C14 C15
PIXMA iP4000-iP5000	C3	C13 C14 C15 C12
PIXMA iP6000D-iP8500	C12	C13 C14 C15 C16 C17
Multipass C20-C30-C50-C70-C80	C1 C20 C2 C21	
Smartbase MP: C190-C200-360-370-390	C10 C20 C11 C21	
SmartBase MP C400-C600F-700-730	C3	C4 C5 C6
PIXMA MP110-MP130	C10 C20 C11 C21	
PIXMA MP750-MP760-MP780	C3	C13 C14 C15 C12
Fax B210C-B230C	C1 C20 C2 C21	






CANON  
Printers

OPTIJET CODE	CANON CODE
C1 C20	BCI 21 BK
C2 C21	BCI 21 C
C3	BCI 3EBK
C4	BCI 3EC
C5	BCI 3EM
C6	BCI 3EY
C7	BCI 3EPC
C8	BCI 3EPM
C9	BCI 3EPB
C10 C20	BCI 24BK
C11 C21	BCI 24C
C12	BCI 6BK
C13	BCI 6C
C14	BCI 6M
C15	BCI 6Y
C16	BCI 6PC
C17	BCI 6PM





BLACK COLOR CYAN MAGENTA YELLOW  

 PHOTO BLACK PHOTO CYAN PHOTO MAGENTA  

 RESETER REFILL KIT  
 CHIP RESETER

			
DESKJET 350		H6	
DESKJET 450C/450cbi	H10	H11	RH2 RH4
DESKJET 600/600C	H2	H6	
DESKJET 610C/610CL/612C/630C/632C/648/656/640C/642C/648C/656C/656CVR	H5	H6	
DESKJET 660C/660cse/670C/670tv/672C/680C/682C/690C/692C/693C/694C/695C/695ccil/697C	H2	H6	
DESKJET 710C/712C/720C/722C	H3	H7	RH1
DESKJET 810C/812C	H4	H7	RH1
DESKJET 815C	H3	H7	RH1
DESKJET 820C/820cxil/820ce	H3		RH1
DESKJET 825C/825cvr	H4	H8	RH1 RH3
DESKJET 830C/832C	H3	H7	RH1
DESKJET 840C/842C/843C/845C/845cvr	H4	H8	RH1 RH3
DESKJET 850C/850cxil/855C/855cse/870cse/870cxi	H3		RH1
DESKJET 880C/882C/890cse/890cxil/895cxil/895cse	H3	H7	RH1
DESKJET 916C/920C/920cxil/920cvr	H4	H9	RH1 RH3
DESKJET 930C/932C/935C	H3	H9	RH1 RH3
DESKJET 940c/940cvr	H4	H9	RH1 RH3
DESKJET 950C/952C/955C/959C/960C/970cse/970cxil/980C/980cxil/990cm/990cse/990cxil/995C	H3	H9	RH1 RH3
DESKJET 1000C/1100C	H3		RH1
DESKJET 1120C	H3	H7	RH1
DESKJET 1180C/1220C/1220ps/1280	H3	H9	RH1 RH3
DESKJET 1600C	H3		RH1
DESKJET 3810/3816/3820/3822	H4	H9	RH1 RH3
DESKJET 5100/5550/5600/5850	H10	H11	RH2 RH4
DESKJET 6122/6127/9300	H3	H9	RH1 RH3
DESKJET 9600/9650/9670/9680	H10	H11	RH2 RH4
DESKWRITER 600/660C	H2	H6	
DESIGNJET 700/750C/750C+/755CMI/755CM+	H3		RH1
OFFICEJET 500/520/570/580/590/600/610/630/635/700/710/720/725	H2	H6	
OFFICEJET 750/950	H4	H9	RH1 RH3
OFFICEJET 1150C/1150cse	H3		RH1
OFFICEJET 1170C/1170cse/1175C/1175cse/1175cxi	H3	H7	RH1
OFFICEJET 4100/4105/4110/4215/4255	H10	H11	RH2 RH4
OFFICEJET 5105/5110/5110xi/5110v	H4	H9	RH1 RH3
OFFICEJET 5500/5505/5508/5510/5510xi/5510v/5515/5550/6110/6110xi/6110v	H10	H11	RH2 RH4
OFFICEJET G55/G55xi/G85/G85xi/G95/K60/K60xi/K80/K80xi	H3	H9	RH1 RH3
OFFICEJET R40/R40xi/R45/R60/R65/R80/R80xi/T45/T45xi/HP/T65/T65xi	H3	H7	RH1
OFFICEJET V30/V40/V40xi/V45	H4	H9	RH1 RH3
PRINTER SCANNER COPIER 370/380	H2	H6	
PRINTER SCANNER COPIER 500/500cxi	H4	H7	RH1
PRINTER SCANNER COPIER 750/750xi/950/950vr/950xi	H4	H9	RH1 RH3
PSC series 1110/1210/1215/1310/1315/1340/1345/1350/1350xi/1350V/1355/2105/2110/2170/2171/2175/2179/2210/2405/2410/2410xi/2410v/2420/2510/4215/4255	H10	H11	RH2 RH4
FAX 100/130/230		H11	RH4
FAX 910/920	H2		
FAX 925xi/1010/1010xi/1020/1020xi	H5		
FAX 1220/1220 xi	H3	H9	RH1 RH3
FAX 1230/1230 xi	H4	H9	RH1 RH3
COLOR COPIER 110/120	H3		RH1
COLOR COPIER 140/145/150/155/160/170	H3	H7	RH1
COLOR COPIER 180/190	H3	H9	RH1 RH3
COLOR COPIER 210/210LX	H3		RH1
COLOR COPIER 260/270	H3	H7	RH1
COLOR COPIER 280/290	H3	H9	RH1 RH3
COLOR COPIER 410	H10	H11	RH2 RH4
PHOTOSMART 900/1000/1100/1100xi/1115/1215/1215vm/1218/1218xi/1315	H3	H9	RH1 RH3
PHOTOSMART 100/130/145/230/245		H11	RH4
PHOTOSMART 7150/7260/7345/7350/7450/7550/7660/7755/7760/7762/7960	H10	H11	RH2 RH4



OPTIJET CODE	HP CODE
H2 ●	HP 29 • 51629A
H3 ●	HP 45 • 51645A
H4 ●	HP 15 • C6615A
H5 ●	HP 20 • C6614D
H6 ●●●	HP 49 • 51649A
H7 ●●●	HP 23 • C1823D
H8 ●●●	HP 17 • C6625A
H9 ●●●	HP 78 • C6578A
H10 ●	HP 56 • C6656A
H11 ●●●	HP 57 • C6657A
RH1 ● 	HP 15 • 45
RH2 ● 	HP 27 • 56
RH3 ●●● 	HP 17 • 78
RH4 ●●● 	HP 28 • 57



Jetprinter 1000-1020-1100-2030-2050-2055-3000	L3
Jetprinter 3200-5000-5700-5770-7000-7200	L1
Jetprinter X125	L1
Jetprinter Z11-Z31	L1
Jetprinter Z42-Z43-Z45-Z51-Z52-Z53	L1
Optracolor 40-45	L1
Optracolor X63-X73-X83-X85	L1
Execjet II-Ilc - Winwriter 100-150c - Medlay 4c-5x-4sx	L3

OPTIJET CODE	LEXMARK CODE
L1 ●	N.70 - 12A1970
L3 ●	13400HCE



80 years of innovation in photography

E-mail: optijet@ferraniait.com • Web site: www.ferraniait.com/optijet

OptiJet inkjet solutions



EXCELLENT PRINTING WITH OPTIJET PHOTO PAPERS!